



1. Turn off the general switch
2. Drill & make holes
3. Apply plastic anchors with screws
4. Connect wires
5. Put the canopy in place

6. Apply side screws
7. Insert the bulb
8. Put the glass in place
9. Turn on general switch